

Tractor R-1/R-4



Alpha-Akuret

Alpha Super Side R-4

Code	Size	Ply	Description	O.D.	Weight	# / 32
99010L	16.9 x 24	12	Alpha Super Side R-4 Tbls	51.52	202.4	32
99020L	17.5L24	12	Alpha Super Side R-4 Tbls	48.84	179.3	32
99030	19.5L24	14	Alpha Super Side R-4 Tbls	51.74	239.8	36
99040	21L24	16	Alpha Super Side R-4 Tbls	54.24	275	40

Tractor R-1/R-4



Geotrac Tire

R-4

Code	Size	Ply	Description	O.D.	Weight	# / 32
20-280L	14.9 x 24	8	Geotrac R-4 Tbls	48.9	150.7	25
20-284L	16.9 x 24	8	Geotrac R-4 Tbls	52	138	28
20-288L	17.5L24	8	Geotrac R-4 Tbls	49.2	140	28
20-292L	18.4 x 24	10	Geotrac R-4 Tbls	54.1	193	35
20-296L	19.5L24	12	Geotrac R-4 Tbls	50.2	194	28
20-298L	21L24	12	Geotrac R-4 Tbls	54.2	223	35
20-655L	16.9 x 28	12	Geotrac R-4 Tbls	55.5	218.2	35
20-658L	21L28	14	Geotrac R-4 Tbls	44.5	302.6	36

Tractor R-1/R-4



Solideal Tire Solideal R-4

Code	Size	Ply	Description	O.D.	Weight	# / 32
1041 1210	14.9 x 24	8	Solideal R-4 Tbls	48.7	147	33
1041 1215	16.9 x 24	8	Solideal R-4 Tbls	51.1	186	33
1041 1235	17.5L 24	8	Solideal R-4 Tbls	49.5	194	32
1041 1250	19.5L 24	12	Solideal R-4 Tbls	51.6	229	37
1041 1260	21L 24	12	Solideal R-4 Tbls	53.9	237	40
1041 1265	18.4 x 26	12	Solideal R-4 Tbls	56.5	182	32
1041 1280	16.9 x 28	8	Solideal R-4 Tbls	55.4	192	37
1041 1290	18.4 x 28	10	Solideal R-4 Tbls	58	225	28
1041 1295	21L 28	10	Solideal R-4 Tbls	44.5	302	36